




Power-Pad HD Lite[®]
SAFE-USE INSTRUCTIONS




Use the Power-Pad HD Lite only for the intended purposes. Respect the load capacity and limiting factors. To be used only in the configuration of the setup guide below. (Page 2)




To be used on firm, level ground.
Always ensure that the Power-Pad HD Lite is placed on firm, level ground and is stable before using it to support equipment.




Do not exceed the rated working load capacity of the Power-Pad HD Lite, as this may cause it to fail and result in equipment damage, injury, or even death.




Do not use Power-Pad HD Lite over voids.




Make sure that the load is centered on the Power-Pad HD Lite.



Always inspect the Power-Pad HD Lite before use, to ensure it is in good condition and free from any cracks, deformations, or damage that may affect its structural integrity.



Use all lifting points provided when lifting the Power-Pad HD Lite.




Always cordon off the area around the Power-Pads HD Lite to reduce the tripping hazard.




INTENDED USE

The Power-Pad HD Lite is designed to increase ground bearing area and distribute the applied load, reducing ground bearing pressure on heavy equipment, such as mobile cranes and aerial lifts. Power-Pad HD Lite enables weight distribution of equipment reducing the risk of sinking or tipping over.

Do not exceed the maximum working load ratings.  If the Power-Pad HD Lite is loaded to the point that the pad is fracturing, splitting, cracking, or deforming the maximum load rating may have been exceeded, or the Power-Pad HD Lite may have been placed on an uneven surface. When damaged, immediately remove the damaged Power-Pad(s) HD Lite from operation.

Limited Factors

SURFACE STABILITY




- 1) To be used on firm, level ground.
- 2) Respect the maximum working load capacity.
- 3) Pad capacity is based on a minimum of 650 mm. diameter being applied on the Power-Pad HD Lite.

SCAN QR CODE FOR SAFE-USE INSTRUCTIONS



Power-Pad HD Lite[®]

USER GUIDE



STEP 1
Inspect the Power-Pad HD Lite for any damage or defects that may affect its structural integrity.





STEP 2
TO BE USED ON FIRM, LEVEL GROUND.
Identify the correct location to place the Power-Pad HD Lite, ensuring that the ground is firm and level.




STEP 3
Use all lifting points provided on the Power-Pad HD Lite when lifting in to position.




STEP 4
Lifting points are designed to lift up to 4 stacked Power-Pads HD Lite. Do not exceed this amount.




STEP 5
Strongly recommended to use EF400 Etha foam (50mm) under the Power-Pad HD Lite to prevent foreign bodies damaging the pad.




STEP 6
Pad Capacity is based on a min. 650 mm diameter being applied. Always ensure that the equipment is positioned over the center of the Power-Pad HD Lite and that the load is evenly distributed across the surface.



STEP 7
Always cordon off the area around the Power-Pad HD Lite to reduce the tripping hazard.



STEP 8
Ensure that all PowerPads HD Lite are placed correctly and on firm level ground, before use.



EXAMPLE
Power-Pad[®]

S/N: TMC255304
WLL: 1100Tonne
TARE: 308KG

SCAN HERE FOR TECHNICAL DATA

S/N : Serial number
WLL: Working Load Limit
TARE: Unladen weight

For the Power-Pad HD Lite capacities refer to the manufacturers test certificate or product data label attached.

* If the product data label is absent, please contact TMC Lifting:
+44 (0) 1733 211339