



Power-Pad HD[®]


SAFE-USE INSTRUCTIONS




Use the Power-Pad HD only for the intended purposes. Respect the load capacity and limiting factors. To be used only in the configuration of the setup guide below. (Page 2)




To be used on firm, level ground.
Always ensure that the Power-Pad HD is placed on firm, level ground and is stable before using it to support equipment.




Do not exceed the rated working load capacity of the Power-Pad HD, as this may cause it to fail and result in equipment damage, injury, or even death.




Do not use Power-Pad HD over voids.




Make sure that the load is centered on the Power-Pad HD.



Always inspect the Power-Pad HD before use, to ensure it is in good condition and free from any cracks, deformations, or damage that may affect its structural integrity.



Use all lifting points provided when lifting the Power-Pad HD.




Always cordon off the area around the Power-Pads HD to reduce the tripping hazards.




INTENDED USE

The Power-Pad HD is designed to increase ground bearing area and distribute the applied load, reducing ground bearing pressure on heavy equipment, such as mobile cranes and aerial lifts. Power-Pad HD enables weight distribution of equipment preventing it from sinking or tipping over.

Do not exceed the maximum working load ratings.  If the Power-Pad HD is loaded to the point that the pad is fracturing, splitting, cracking, or deforming the maximum load rating may have been exceeded or the Power-Pad HD may have been placed on an uneven surface. When damaged, immediately remove the damaged Power-Pad(s) HD from operation.

Limited Factors

SURFACE STABILITY


KG

USE MINIMUM 1/3rd PAD AREA


- 1) To be used on firm, level ground.
- 2) Respect the maximum working load capacity.
- 3) Pad capacity is based on a minimum 1/3rd area being applied in the centre of the Power-Pad HD and used on firm level ground.

SCAN QR CODE FOR SAFE-USE INSTRUCTIONS



Power-Pad HD[®]

USER GUIDE




STEP 1
Inspect the Power-Pad HD for any damage or defects that may affect its structural integrity.




STEP 2
TO BE USED ON FIRM, LEVEL GROUND.
Identify the correct location to place the Power-Pad HD, ensuring that the ground is firm and level.




STEP 3
Use all lifting points provided on the Power-Pad HD when lifting in to position.




STEP 4
Lifting points are designed to lift up to 4 stacked Power-Pads HD. Do not exceed this amount.



STEP 5
Always ensure that the equipment is positioned over the center of the Power-Pad HD and that the load is evenly distributed across the surface.



STEP 6
Always cordon off the area around the Power-Pad HD to reduce the tripping hazard.



STEP 7
Ensure that all Power-Pads HD are placed correctly and on firm level ground, before use.



S/N : Serial number
WLL: Working Load Limit
TARE: Unladen weight

For the Power-Pad HD capacities refer to the manufacturers test certificate or product data label attached.

* If the product data label is absent, please contact TMC Lifting:
+44 (0) 1733 211339